

Tigullio Hamradio

Tabella conversione DBm/Watt

DBm	Volt	mW		DBm	Volt	Watt		DBm	Volt	Watt
0	0.22	1.00		20	2.24	0.10		40	22.4	10.0
1	0.25	1.26		21	2.51	0.12		41	25.1	12.0
2	0.28	1.58		22	2.82	0.16		42	28.2	16.0
3	0.31	2.00		23	3.16	0.20		43	31.6	20.0
4	0.35	2.51		24	3.54	0.25		44	35.4	25.0
5	0.39	3.16		25	3.98	0.31		45	39.8	31.0
6	0.44	4.00		26	4.46	0.40		46	44.6	40.0
7	0.50	5.00		27	5.01	0.50		47	50.1	50.0
8	0.56	6.31		28	5.62	0.63		48	56.2	63.0
9	0.63	8.00		29	6.30	0.80		49	63.0	80.0
10	0.70	10.0		30	7.07	1.00		50	70.7	100
11	0.79	12.5		31	7.93	1.26		51	79.3	126
12	0.89	15.8		32	8.90	1.58		52	89.0	158
13	1.00	20.0		33	10.0	2.00		53	100	200
14	1.12	25.0		34	11.2	2.51		54	112	251
15	1.26	31.6		35	12.6	3.16		55	126	316
16	1.41	40.0		36	14.1	4.00		56	141	400
17	1.58	50.0		37	15.8	5.00		57	158	500
18	1.78	63.1		38	17.8	6.31		58	177	631
19	1.99	80.0		39	19.9	8.00		59	199	800
20	2.24	100		40	22.4	10.0		60	224	1000